
INDEX

GENERAL CATALOGUE


TURNING TOOLS // ROTATING TOOLS



INDEX

INDEX FOR TOOL NUMBER

| | |
|--------|----|
| A..... | 2 |
| B..... | 2 |
| C..... | 3 |
| D..... | 4 |
| E..... | 5 |
| F..... | 5 |
| G..... | 6 |
| H..... | 6 |
| I..... | 7 |
| J..... | 7 |
| K..... | 7 |
| L..... | 7 |
| M..... | 7 |
| N..... | 8 |
| O..... | 9 |
| P..... | 9 |
| Q..... | 9 |
| R..... | 9 |
| S..... | 10 |
| T..... | 11 |
| U..... | 12 |
| V..... | 13 |
| W..... | 14 |
| X..... | 14 |
| Z..... | 14 |



INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|------------------------|--|-----------|-------------------------|--|----------------|
| A | | | | | |
| A000-DCLNR/L12 | DOUBLE CLAMP DIMPLE BAR | E014 | APX3000R000WA000A | APX3000 type end mill | K040 |
| A000-DDUNR/L15 | DOUBLE CLAMP DIMPLE BAR | E014 | APX4000-000A00RA | APX4000 type face mill | K048 |
| A000-DSKNR/L12 | DOUBLE CLAMP DIMPLE BAR | E015 | APX4000R000M00A00 | APX4000 type end mill | K048 |
| A000-DTFNR/L16 | DOUBLE CLAMP DIMPLE BAR | E015 | APX4000R000SA000A | APX4000 type end mill | K047 |
| A000-DVUNR/L16 | DOUBLE CLAMP DIMPLE BAR | E016 | APX4000R000WA000A | APX4000 type end mill | K046 |
| A000-DWLNR/L00 | DOUBLE CLAMP DIMPLE BAR | E016 | APX4K-000A00A000RA | APX4000 type end mill | K052 |
| A000-PCLNR/L00 | P type boring bar | E037 | APX4KR0000000000000000A | APX4000 type end mill | K052 |
| A000-PDQNR/L15 | P type boring bar | E038 | AQXR00000A/N00S/L | AQX type end mill | K068,K069 |
| A000-PDUNR/L00 | P type boring bar | E037 | AQXR000M00A00 | AQX type end mill | K070 |
| A000-PDZNR/L15 | P type boring bar | E039 | ARPOP-000A00AR | ARP type face mill | K136,K141 |
| A000-PSKNR/L00 | P type boring bar | E036 | ARPOP-000SA00L/M | ARP type end mill | K138,K141 |
| A000-PTFNR/L00 | P type boring bar | E036 | ARPOP-000AM0000 | ARP type end mill | K139,K141 |
| A000-PWLNR/L06 | P type boring bar | E038 | ARP6PR0000000A | ARP type face mill | K137 |
| AEMW00000000ER | Insert (For BAE type end mill) | J021 | ASS0 | Spring (For AJX/BRE/CV type cutter) | C032 |
| AHX440S-00000000R | AHX440S type face mill | K023 | | | K076—K079,K134 |
| AHX640S-00000000R | AHX640S type face mill | K027 | ASX400-0000000R | ASX400 type face mill | K036 |
| AHX640W-00000000R/L | AHX640W type face mill | K025 | ASX400R000M16 | ASX400 type end mill | K037 |
| AJS0000T00 | Clamp screw | M003 | ASX400R000S32 | ASX400 type end mill | K037 |
| AJX00-000 | AJX type face mill | K084 | ASX445-0000000R/L | ASX445 type face mill | K017 |
| AJX00-0000000R | AJX type face mill | K076 | ASX445R000S32 | ASX445 type end mill | K018 |
| AJX00R0000000 | AJX type face mill | K076,K084 | AXD4000-0000000R0 | AXD4000 type face mill | K054 |
| AJX00R000AM00 | AJX type face mill | K077 | AXD4000R000SA000A/B | AXD4000 type end mill | K055 |
| AJX00R000SA00S/L/ES/EL | AJX type end mill | K078,K079 | AXD7000-0000000R0 | AXD7000 type face mill | K060 |
| AM2MB | ALIMASTER end mill | I306 | AXD7000R000000A-H63A | AXD7000 type end mill | K061 |
| AM2MR | ALIMASTER end mill | I301 | AXD7000R000SA00S0 | AXD7000 type end mill | K060 |
| AM2SC | ALIMASTER end mill | I302 | B | | |
| AM2SCRB | ALIMASTER end mill | I307,I308 | BCP000 | Shim pin | M013 |
| AM3MF | ALIMASTER end mill | I304 | BF-CCGT00000000002 | Insert (Class G tolerance) | B036 |
| AM3SS | ALIMASTER end mill | I303 | BF-CNGG00000000004 | Insert (Class G tolerance) | B022 |
| AM3SSRB | ALIMASTER end mill | I310,I311 | BF-CNGM00000000002 | Insert (Class G tolerance) | B023 |
| AM4MF | ALIMASTER end mill | I305 | BF-DCGT00000000002 | Insert (Class G tolerance) | B038 |
| AMMR | ALIMASTER end mill | I314 | BF-DNGG00000000004 | Insert (Class G tolerance) | B025 |
| AMS0 | Clamp bridge | M014 | BF-DNGM00000000002 | Insert (Class G tolerance) | B027 |
| AMSR | ALIMASTER end mill | I312 | BM-CCGT0000000TA2 | Insert (Class G tolerance) | B036 |
| AMSRRB | ALIMASTER end mill | I316 | BM-CNGM0000000TA2 | Insert (Class G tolerance) | B023 |
| AOGT0000000PEFR-GM | Insert (For APX3000 type cutter) | J020,K043 | BM-DCGT0000000TA2 | Insert (Class G tolerance) | B039 |
| AOMT0000000PEER-M/H | Insert (For APX3000*4000 type cutter) | J020 | BM-DNGM0000000TA2 | Insert (Class G tolerance) | B027 |
| | | K043,K049 | BM-TNGM0000000003 | Insert (Class G tolerance) | B030 |
| AOX445-063A04R | AOX445 type face mill | K030 | BOES101 | Set bolt | M009 |
| AOX445R0000000 | AOX445 type face mill | K030 | BPT322 | Shim | M010 |
| AOX445R000S32 | AOX445 type end mill | K030 | BRPON-0000000R | BRP type face mill | K088 |
| APGT0000000PDFR-G2 | Insert (For BAP300*400 type cutter) | J021 | BRPONR000M00 | BRP type end mill | K088 |
| APMT0000000PDER-H0 | Insert (For BAP300*400/SRM2 type cutter) | J021,K122 | BRPOP-0000000R | BRP type face mill | K088 |
| APMT0000000PDER-M0 | Insert (For BAP300*400/SRM2 type cutter) | J021,K122 | BRS000 | Clamp screw | M003 |
| APX3000-000A00RA | APX3000 type face mill | K042 | BTahr/L0000-50 | Small tools holder (External back turning) | D012 |
| APX3000R0000000A | APX3000 type face mill | K042 | BTAT0000000R/L-B | Insert for external back turning | D012 |
| APX3000R000M00A | APX3000 type end mill | K042 | BTAT605000RX | Insert for external back turning | D012 |
| APX3000R000SA000A | APX3000 type end mill | K041 | BTBT0000000R/L-B | Insert for external back turning | D013 |
| | | | BTBT606000R/L | Insert for external back turning | D013 |

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|------------------------------|--|-----------|------------------------|---------------------------------------|-----------|
| BTVHR ○○○○○-75○ | Small tools holder (External back turning) ... | D014 | CCMT ○○○○○○-FM | Insert (Class M tolerance) | A133 |
| BTVT ○○○○○○○R-B | Insert for external back turning | D014 | CCMT ○○○○○○-FP | Insert (Class M tolerance) | A133 |
| BXD4000 -○○○○○○○RA/B | BXD4000 type face mill | K064 | CCMT ○○○○○○-FV | Insert (Class M tolerance) | A133 |
| BXD4000R ○○○○○○○A/B | BXD4000 type face mill | K064 | CCMT ○○○○○○-LM | Insert (Class M tolerance) | A134 |
| BXD4000R ○○○SA○○ELA/B | BXD4000 type end mill | K065 | CCMT ○○○○○○-LP | Insert (Class M tolerance) | A134 |
| BXD4000R ○○○SA○○LA/B | BXD4000 type end mill | K065 | CCMT ○○○○○○-MK | Insert (Class M tolerance) | A135 |
| BXD4000R ○○○SA○○SA/B | BXD4000 type end mill | K065 | CCMT ○○○○○○-MM | Insert (Class M tolerance) | A135 |
| C | | | CCMT ○○○○○○-MP | Insert (Class M tolerance) | A135 |
| ○○○SCLCR ○○ | MICRO-DEX boring bar, S type boring bar (Carbide shank) | E017,E031 | CCMT ○○○○○○-MW | Insert (Class M tolerance) | A136 |
| ○○○SDQCR ○○ | S type boring bar (Carbide shank) | E032 | CCMT ○○○○○○-SW | Insert (Class M tolerance) | A134 |
| ○○○SDUCR ○○ | S type boring bar (Carbide shank) | E030 | CCMW ○○○○○○ | Insert (Class M tolerance) | A137,B051 |
| ○○○STFCR ○○ | S type boring bar (Carbide shank) | E029 | CCMX ○○○○○○EN○ | Insert (For DCCC type end mill) | J022,K101 |
| ○○○STUCR06 | MICRO-DEX boring bar (Carbide shank) ... | E018 | CCP ○○ | Shim pin | M013 |
| ○○○SVQCR ○○ | S type boring bar (Carbide shank) | E033 | CCTC1 | Clamp bridge | M014 |
| ○○○SWUBR ○○ | MICRO-DEX boring bar (Carbide shank) ... | E017 | CE4SRB/CE6SRB | Ceramic end mill | I295 |
| ○○FR-BLS | MICRO-MINI boring bar (Solid carbide)... | E023,F115 | CESPR ○○○S○○ | CESP type end mill | K124 |
| ○○HR-BLS | MICRO-MINI boring bar (Solid carbide)... | E023,F115 | CFSPR ○○○S○○ | CFSP type end mill | K124 |
| CA ○○○ | Clamp bridge | M014 | CG ○○RS-○○○ | MICRO-MINI TWIN | F111 |
| CAS ○○T | Set screw | M003 | CGSPR ○○○S○○ | CGSP type end mill | K124 |
| CB ○○RS | MICRO-MINI TWIN | E020 | CK ○○○ | Clamp bridge | M014 |
| CB ○○RS-○○ | MICRO-MINI TWIN | E020 | CKW6 | Clamp bridge | M015 |
| CB ○○RS-○○B | MICRO-MINI TWIN | E020 | CNGA ○○○○○○ | Insert (Class G tolerance) | B023 |
| CB ○○RS-B | MICRO-MINI TWIN | E020 | CNGG ○○○○○○-FJ | Insert (Class G tolerance) | A094 |
| CBJPR ○○○S○○ | CBJP type end mill | K126 | CNGG ○○○○○○-MJ | Insert (Class G tolerance) | A095 |
| CBMPR ○○○S○○ | CBMP type end mill | K126 | CNGG ○○○○○○-PK | Insert (Class G tolerance) | A094 |
| CBN2XLB | CBN end mill | I297 | CNGN ○○○○○○ | Insert (Class G tolerance) | B033 |
| CBN2XLRB | CBN end mill | I299 | CNMA ○○○○○○ | Insert (Class M tolerance) | A100,B048 |
| CBS ○ | Breaker piece | M016 | CNMG ○○○○○○-HAS | Insert (Class M tolerance) | A100 |
| CBS ○D | Breaker piece | M016 | CNMG ○○○○○○ | Insert (Class M tolerance) | A097 |
| CBT ○ | Breaker piece | M016 | CNMG ○○○○○○-FH | Insert (Class M tolerance) | A094 |
| CBT ○○ | Breaker piece | M016 | CNMG ○○○○○○-FS | Insert (Class M tolerance) | A094 |
| CBT ○○○○ | Breaker piece | M016 | CNMG ○○○○○○-FY | Insert (Class M tolerance) | A094 |
| CCET ○○○○○○○R/L-SN | Insert (Class E tolerance) | A136,A137 | CNMG ○○○○○○-GH | Insert (Class M tolerance) | A099 |
| CCET ○○○○○○○R/L-SR | Insert (Class E tolerance) | A136 | CNMG ○○○○○○-GJ | Insert (Class M tolerance) | A099 |
| CCET ○○○○○○○R/LW-SN | Insert (Class E tolerance) | A137 | CNMG ○○○○○○-GK | Insert (Class M tolerance) | A096 |
| CCGH ○○○○○○○R/L-F | Insert (Class G tolerance) | A134 | CNMG ○○○○○○-GM | Insert (Class M tolerance) | A097 |
| CCGT ○○○○○○○-AZ | Insert (Class G tolerance) | A133 | CNMG ○○○○○○-LK | Insert (Class M tolerance) | A095 |
| CCGT ○○○○○○○-FJ | Insert (Class G tolerance) | A133 | CNMG ○○○○○○-LM | Insert (Class M tolerance) | A094 |
| CCGT ○○○○○○○L-F | Insert (Class G tolerance) | A134 | CNMG ○○○○○○-LP | Insert (Class M tolerance) | A094 |
| CCGT ○○○○○○○R/L-SN | Insert (Class G tolerance) | A137 | CNMG ○○○○○○-LS | Insert (Class M tolerance) | A095 |
| CCGT ○○○○○○○R/L-SS | Insert (Class G tolerance) | A135 | CNMG ○○○○○○-MA | Insert (Class M tolerance) | A097 |
| CCGT ○○○○○○○-SMG | Insert (Class G tolerance) | A137 | CNMG ○○○○○○-MH | Insert (Class M tolerance) | A097 |
| CCGW ○○○○○○○ | Insert (Class G tolerance) | A138 | CNMG ○○○○○○-MJ | Insert (Class M tolerance) | A095 |
| CCGW ○○○○○○○FS | Insert (Class G tolerance) | B036 | CNMG ○○○○○○-MK | Insert (Class M tolerance) | A096 |
| CCK ○○ | Clamp bridge | M014 | CNMG ○○○○○○-MM | Insert (Class M tolerance) | A096 |
| CCMH ○○○○○○○-MV | Insert (Class M tolerance) | A136 | CNMG ○○○○○○-MP | Insert (Class M tolerance) | A096 |
| CCMH ○○○○○○○-SV | Insert (Class M tolerance) | A134 | CNMG ○○○○○○-MS | Insert (Class M tolerance) | A097 |
| CCMT ○○○○○○○ | Insert (Class M tolerance) | A135 | CNMG ○○○○○○-MW | Insert (Class M tolerance) | A098 |
| | | | CNMG ○○○○○○○-RK | Insert (Class M tolerance) | A098 |
| | | | CNMG ○○○○○○○-RM | Insert (Class M tolerance) | A098 |

INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|-----------------|--|------------------|------------------|--|------------|
| CNMG○○○○○-RP | Insert (Class M tolerance) | A098 | CT○○RS-M○○ | MICRO-MINI TWIN | G026 |
| CNMG○○○○○-RS | Insert (Class M tolerance) | A099 | CT32T1 | Shim | M011 |
| CNMG○○○○○-SA | Insert (Class M tolerance) | A095 | CTAHR/L○○○○-120 | Small tools holder (External cutting off) | D018 |
| CNMG○○○○○-SH | Insert (Class M tolerance) | A095 | CTAHR1010-120S | Small tools holder (External cutting off) | D018 |
| CNMG○○○○○-SW | Insert (Class M tolerance) | A095 | CTAT○○○○○○○-B | Insert for cutting off | D019 |
| CNMG○○○○○-SY | Insert (Class M tolerance) | A095 | CTAT○○○○○○○-BX | Insert for cutting off | D019 |
| CNMM○○○○○-HL | Insert (Class M tolerance) | A099 | CTAT○○○○○○○LL/RR | Insert for cutting off | D019 |
| CNMM○○○○○-HM | Insert (Class M tolerance) | A099 | CTBHR/L○○○○-160 | Small tools holder (External back turning, External cutting off)... | D013, D020 |
| CNMM○○○○○-HR | Insert (Class M tolerance) | A100 | CTBT○○○○○○○-B | Insert for cutting off | D020 |
| CNMM○○○○○-HV | Insert (Class M tolerance) | A100 | CTCHR/L○○○○-200 | Small tools holder (External cutting off) | D021 |
| CNMM○○○○○-HX | Insert (Class M tolerance) | A100 | CTCT○○○○○○○-B | Insert for cutting off | D021 |
| CNMM○○○○○-HZ | Insert (Class M tolerance) | A099 | CTDHR/L1616-○○○ | Small tools holder (External cutting off) | D022 |
| CNMN○○○○○ | Insert (Class M tolerance) | A130 | CTDT○○○○○○○-B | Insert for cutting off | D022 |
| CPGT○○○○○ | Insert (Class G tolerance) | A139, B051 | CTDT○○○○○○○-BS | Insert for cutting off | D022 |
| CPGT○○○○○R/L-F | Insert (Class G tolerance) | A139 | CTE○○TN/P○○ | Shim (For MMTE holder) | G012 |
| CPMH○○○○○-FV | Insert (Class M tolerance) | A139 | CTEHR/L1616-○○○ | Small tools holder (External cutting off) | D023 |
| CPMH○○○○○-MV | Insert (Class M tolerance) | A139 | CTET○○○○○○○-B | Insert for cutting off | D023 |
| CPMH○○○○○R/L-F | Insert (Class M tolerance) | A139 | CTET○○○○○○○-BS | Insert for cutting off | D023 |
| CPMH○○○○○-SV | Insert (Class M tolerance) | A139 | CTI○○TN/P○○ | Shim (For MMTI holder) | G013 |
| CPMT○○○○ZPEN-M○ | Insert (For PMR type end mill) | J022, K132 | CWAHX640WN | Wedge | K025 |
| CPMX○○○○○ | Insert (Class M tolerance) | A139 | CWAOX445N | Wedge | K030 |
| CPT○○ | Side lock plate | C016—C018, C023 | CWSG20SN | Wedge-S | K031 |
| CR○ | Stop ring | G012, G013, H016 | CWSG20TR | Wedge-T | K031 |
| CR○○RS-○○ | MICRO-MINI TWIN | E021 | D | | |
| CR○○RS-○○B | MICRO-MINI TWIN | E021 | DC○○○OT | Clamp screw | M003 |
| CRN2MB | CRN end mill | I265 | DCCCR○○○○S○○ | DCCC type end mill | K100 |
| CRN2MRB | CRN end mill | I271 | DCET○○○○○R/L-SN | Insert (Class E tolerance) | A143 |
| CRN2MS | CRN end mill | I259 | DCET○○○○○R/L-SR | Insert (Class E tolerance) | A142 |
| CRN2XL | CRN end mill | I261, I262 | DCET○○○○○R/LW-SN | Insert (Class E tolerance) | A143 |
| CRN2XLB | CRN end mill | I267—I269 | DCGT○○○○○-AZ | Insert (Class G tolerance) | A140 |
| CRN2XLRB | CRN end mill | I273, I274 | DCGT○○○○○R/L-F | Insert (Class G tolerance) | A140 |
| CRN4JC | CRN end mill | I264 | DCGT○○○○○R/L-SN | Insert (Class G tolerance) | A143 |
| CS○ | Clamp screw | M003 | DCGT○○○○○R/L-SS | Insert (Class G tolerance) | A141 |
| CS○○ | Shim | M010 | DCGT○○○○○-SMG | Insert (Class G tolerance) | A143 |
| CS○○○○○OT | Clamp screw | M003 | DCGW○○○○○ | Insert (Class G tolerance) | A144 |
| CS○○○○○OTS | Clamp screw | M003 | DCGW○○○○○FS | Insert (Class G tolerance) | B039 |
| CS○○○OT | Clamp screw | M003 | DCK○○○○ | Clamp bridge | M015 |
| CSF401260T | Clamp screw | M003 | DCLNR/L○○○○○○○ | DOUBLE CLAMP holder | C008 |
| CSVHR/L○○○○ | Small tools holder (For cam tool posts) | D027 | DCLNR/L○○○○○○○-T | DOUBLE CLAMP holder | C008 |
| CSVTB○○○R/L | Insert for external back turning | D028 | DCMT○○○○○ | Insert (Class M tolerance) | A142 |
| CSVTB○○○R-B | Insert for external back turning | D028 | DCMT○○○○○-FM | Insert (Class M tolerance) | A140 |
| CSVTBXL | Insert for external back turning, Copying | D028 | DCMT○○○○○-FP | Insert (Class M tolerance) | A140 |
| CSVTC○○○○R/L | Insert for external cutting off | D028 | DCMT○○○○○-FV | Insert (Class M tolerance) | A140 |
| CSVTC○○○○R-B | Insert for external cutting off | D028 | DCMT○○○○○-LM | Insert (Class M tolerance) | A141 |
| CSVTF○○○R/L | Insert for external front turning | D027 | DCMT○○○○○-LP | Insert (Class M tolerance) | A140 |
| CSVTF○○○R/L-B | Insert for external front turning | D027 | DCMT○○○○○-MK | Insert (Class M tolerance) | A141 |
| CSVTFXL | Insert for external front turning, Copying | D027 | DCMT○○○○○-MM | Insert (Class M tolerance) | A141 |
| CSVTG○○○○○R/L | Insert for grooving | D029 | DCMT○○○○○-MP | Insert (Class M tolerance) | A141 |
| CSVTT60050RR/L | Insert for threading | D029 | | | |
| CT○○ | Shim | M010 | | | |

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|--------------------|------------------------------|---|---------------------|----------------------------|-----------|
| DCMT000000-MV | Insert (Class M tolerance) | A142 | DNMG000000-RS | Insert (Class M tolerance) | A105 |
| DCMT000000-SV | Insert (Class M tolerance) | A141 | DNMG000000-SA | Insert (Class M tolerance) | A102 |
| DCMW000000 | Insert (Class M tolerance) | A144,B052 | DNMG000000-SH | Insert (Class M tolerance) | A102 |
| DCS0 | Spring | C008,C010,C017,C019—C022 E014—E016,H006—H011 | DNMG000000-SY | Insert (Class M tolerance) | A103 |
| DCSVN32 | Shim | M010 | DNMM000000-HL | Insert (Class M tolerance) | A106 |
| DDJNR/L000000 | DOUBLE CLAMP holder | C010 | DNMM000000-HZ | Insert (Class M tolerance) | A106 |
| DDJNR/L000000-15-T | DOUBLE CLAMP holder | C010 | DNMX000000-MW | Insert (Class M tolerance) | A105 |
| DEGX000000-R/L | Insert (For AL holder) | A145 | DNMX000000-SW | Insert (Class M tolerance) | A103 |
| DEGX000000-R/L-F | Insert (For AL holder) | A145,B052 | DTGNR/L000000-16 | DOUBLE CLAMP holder | C017 |
| DF2MB | Diamond(DF) coated end mill | I285 | DTGNR/L000000-16-T | DOUBLE CLAMP holder | C017 |
| DF2XLB | Diamond(DF) coated end mill | I286,I287 | DVJNR/L000000-16 | DOUBLE CLAMP holder | C019 |
| DF3XB | Diamond(DF) coated end mill | I290 | DVJNR/L000000-16 | DOUBLE CLAMP holder | C021 |
| DF4JC | Diamond(DF) coated end mill | I281 | DVNN000000-16 | DOUBLE CLAMP holder | C020 |
| DF4XL | Diamond(DF) coated end mill | I282 | DWLNLR/L000000 | DOUBLE CLAMP holder | C022 |
| DFC4JC | Diamond(DFC) coated end mill | I279 | DWLNLR/L000000-06-T | DOUBLE CLAMP holder | C022 |
| DFCJRT | Diamond(DFC) coated end mill | I280 | | | |
| DFPSRB | Diamond(DF) coated end mill | I292,I293 | E | | |
| DKS0 | Clamp screw | M003 | E00 | Stop ring | C019—C021 |
| DLC2MA | DLC coated end mill | I275 | EGS000000 | Clamp screw | M004 |
| DLC2MB | DLC coated end mill | I277 | ESS42 | Shim | M010 |
| DNGA000000 | Insert (Class G tolerance) | A106,B048 | EST00 | Shim | M010 |
| DNGG000000-FJ | Insert (Class G tolerance) | A101 | F | | |
| DNGG000000-PK | Insert (Class G tolerance) | A101 | FC400890T | Clamp screw | M004 |
| DNGG000000-R/L | Insert (Class G tolerance) | A105 | FCTU000R/L | FCTU type boring bar | E027 |
| DNGM000000-MJ | Insert (Class G tolerance) | A103 | FMAX000BOR | FMAX type face mill | K142 |
| DNGN000000 | Insert (Class G tolerance) | B033 | FSCLC1008R/L-06A | DIMPLE BAR | E007 |
| DNMA000000 | Insert (Class M tolerance) | A106 | FSCLC1008R/L-06E | DIMPLE BAR (Carbide shank) | E007 |
| DNMG000000 | Insert (Class M tolerance) | A105 | FSCLC1008R-06E-0/0 | DIMPLE BAR (Carbide shank) | E007 |
| DNMG000000-FH | Insert (Class M tolerance) | A101 | FSCLP0000R/L-00A | DIMPLE BAR | E007 |
| DNMG000000-FS | Insert (Class M tolerance) | A101 | FSCLP0000R/L-00E | DIMPLE BAR (Carbide shank) | E007 |
| DNMG000000-FY | Insert (Class M tolerance) | A101 | FSCLP0000R-00E-0/0 | DIMPLE BAR (Carbide shank) | E007 |
| DNMG000000-GH | Insert (Class M tolerance) | A106 | FSDQC0000R/L-00A | DIMPLE BAR | E010 |
| DNMG000000-GJ | Insert (Class M tolerance) | A106 | FSDQC0000R/L-00E | DIMPLE BAR (Carbide shank) | E010 |
| DNMG000000-GK | Insert (Class M tolerance) | A104 | FSDUC0000R/L-00A | DIMPLE BAR | E009 |
| DNMG000000-GM | Insert (Class M tolerance) | A104 | FSDUC0000R/L-00E | DIMPLE BAR (Carbide shank) | E009 |
| DNMG000000-LK | Insert (Class M tolerance) | A102 | FSL5000R | FSL5 type boring bar | F116,G030 |
| DNMG000000-LM | Insert (Class M tolerance) | A102 | FSTU000R/L | FSTU type boring bar | E026 |
| DNMG000000-LP | Insert (Class M tolerance) | A101 | FSTUP0000R/L-00A | DIMPLE BAR | E008 |
| DNMG000000-LS | Insert (Class M tolerance) | A102 | FSTUP0000R/L-00E | DIMPLE BAR (Carbide shank) | E008 |
| DNMG000000-MA | Insert (Class M tolerance) | A104 | FSTUP0000R-00E-0/0 | DIMPLE BAR (Carbide shank) | E008 |
| DNMG000000-MH | Insert (Class M tolerance) | A104 | FSVJB0000R/L-11S | DIMPLE BAR | E013 |
| DNMG000000-MJ | Insert (Class M tolerance) | A103 | FSVJC0000R/L-08S | DIMPLE BAR | E013 |
| DNMG000000-MK | Insert (Class M tolerance) | A103 | FSVPB0000R/L-00A | DIMPLE BAR | E012 |
| DNMG000000-MM | Insert (Class M tolerance) | A103 | FSVPC0000R/L-08A | DIMPLE BAR | E012 |
| DNMG000000-MP | Insert (Class M tolerance) | A103 | FSVUB0000R/L-00A | DIMPLE BAR | E012 |
| DNMG000000-MS | Insert (Class M tolerance) | A104 | FSVUC0000R/L-08A | DIMPLE BAR | E012 |
| DNMG000000-RK | Insert (Class M tolerance) | A105 | FSWL000R/L0 | FSWL type boring bar | E028 |
| DNMG000000-RM | Insert (Class M tolerance) | A105 | FSWUB0000R/L-L3A | DIMPLE BAR | E011 |
| DNMG000000-RP | Insert (Class M tolerance) | A105 | FSWUB0000R/L-L3E | DIMPLE BAR (Carbide shank) | E011 |

INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|-----------------------|--|---------------------|-----------------------|----------------------------------|-------------------------------|
| H | | | | | |
| FSWUB0000R-L3E-0/0 | DIMPLE BAR (Carbide shank) | E011 | H100TH-B00-000 | HSK boring bar holder | H022 |
| FSWUP0000R/L-00A | DIMPLE BAR | E011 | H100TH-EN3232R/L-130 | HSK external turning tool holder | H020 |
| FSWUP0000R/L-00E | DIMPLE BAR (Carbide shank) | E011 | H100TH-EV3232R/L-180 | HSK external turning tool holder | H019 |
| FSWUP0000R-00E-0/0 | DIMPLE BAR (Carbide shank) | E011 | H63TH-A000DCLNR/L12 | HSK DCLN type holder | H008 |
| G | | | | | |
| GCMT040204-U0 | Insert (For TAF type drill) | L164 | H63TH-B00-000 | HSK boring bar holder | H021 |
| GOER1408PXFR2 | Insert (For FMAX type cutter) | J043,K143 | H63TH-DCLNL-L12-3 | HSK DCLN type holder | H008 |
| GPMT000000-U0 | Insert (For TAF type drill) | L164 | H63TH-DCLNR/L-DX12 | HSK DCLN type holder | H006 |
| GT0HR/L0000-000 | Small tools holder (External grooving) | D016 | H63TH-DCMNN-H/L12 | HSK DCMN type holder | H007 |
| GT0T000000R/L-E | Insert for external grooving | D017 | H63TH-DDJNL-L15-3 | HSK DDJN type holder | H011 |
| GT0T000000R/L-U | Insert for external grooving | D016 | H63TH-DDJNR/L-DX15 | HSK DDJN type holder | H009 |
| GT0T000000R-VT | Insert for external grooving | D017 | H63TH-DDNNN-H/L15 | HSK DDNN type holder | H010 |
| GT0TR/L | Insert (Blank) | D017 | H63TH-EN2525R/L-115 | HSK external turning tool holder | H020 |
| GY05016S | Clamp screw | M004 | H63TH-EV2020R/L-105-3 | HSK external turning tool holder | H021 |
| GY06013M | Clamp screw | M004 | H63TH-EV2525R/L-112 | HSK external turning tool holder | H019 |
| GY1B00000000N | Insert (For GY holder) | F014 | H63TH-MGHR/L-DX0000 | HSK MG type holder | H014 |
| GY1G00000000-GFGS | Insert (For GY holder) | B046,F013 | H63TH-MMTENR-H/L16 | HSK MMT type holder | H016 |
| GY2B00000000N | Insert (For GY holder) | F014 | H63TH-MMTER-DX16 | HSK MMT type holder | H016 |
| GY2G00000000N-MF | Insert (For GY holder) | F013 | H63TH-MTHR/L-DX43 | HSK MT type holder | H017 |
| GY2M00000000N-BM | Insert (For GY holder) | F014 | H63TH-PCLNR/L-DX12 | HSK PCLN type holder | H006 |
| GY2M00000000N-GM | Insert (For GY holder) | F012 | H63TH-PCMNN-H/L12 | HSK PCMN type holder | H007 |
| GY2M00000000N-GS | Insert (For GY holder) | F012 | H63TH-PDJNR/L-DX15 | HSK PDJN type holder | H009 |
| GY2M00000000N-GU | Insert (For GY holder) | F012 | H63TH-PDNNN-H/L15 | HSK PDNN type holder | H010 |
| GY2M00000000N-MM | Insert (For GY holder) | F014 | H63TH-PRDCN-H/L12 | HSK PRDC type holder | H012 |
| GY2M00000000N-MS | Insert (For GY holder) | F013 | H63TH-PRGCR/L-DX12 | HSK PRGC type holder | H012 |
| GY2M00000000R/L05-GM | Insert (For GY holder) | F012 | H63TH-SVPBR/L-DX16 | HSK SVPB type holder | H013 |
| GYAR/L000900-D00 | GY boring bar | F080 | H63TH-SVVBH-H/L16 | HSK SVVB type holder | H013 |
| GYAR/L000900-E00 | GY boring bar | F082 | HBH00000 | Clamp screw | M002 |
| GYAR/L000900-F00 | GY boring bar | F084 | HBHA00000 | Clamp screw | M002 |
| GYAR/L000900-G00 | GY boring bar | F084 | HDS00000 | Clamp screw | M009 |
| GYAR/L000900-H00 | GY boring bar | F086 | HFF06015 | Clamp screw | M004 |
| GYDR/L000900-M00R/L | GY holder | F080—F086 | HFF08043H | Clamp screw | M009 |
| GYHR/L0000000-M00R/L | GY holder | F016—F026,F038—F068 | HGM-PT0/0 | Plug | E036—E039 |
| GYHR/L00000050-M00R/L | GY holder | F036 | | | H007,H010,H012,H013,H016,H019 |
| GYHR/L00000090-M00R/L | GY holder | F030—F034,F070—F078 | HKY00D | Driver | M002 |
| GYM00R/L0-D00 | Modular blade | F016,F030,F080 | HKY00F | Flag wrench | M002 |
| GYM00R/L0-D00-000 | Modular blade | F038—F040,F070 | HKY00L | L-wrench | M002 |
| GYM00R/L0-E00 | Modular blade | F018,F030,F082 | HKY00R | L-wrench | M002 |
| GYM00R/L0-E00-000 | Modular blade | F042—F044,F070 | HKY00T | T-wrench | M002 |
| GYM00R/L0-F00 | Modular blade | F020,F032,F084 | HKY00W | Flag wrench | M002 |
| GYM00R/L0-F00-000 | Modular blade | F046—F052,F072 | HLS0 | Lever spring | K128 |
| GYM00R/L0-G00 | Modular blade | F022,F032,F084 | HP00 | Clamp pin | E036—E039 |
| GYM00R/L0-G00-000 | Modular blade | F054—F058,F074 | HS00 | Clamp screw | M004 |
| GYM00R/L0-H00 | Modular blade | F024,F034,F086 | HSC00000 | Clamp screw | M002 |
| GYM00R/L0-H00-000 | Modular blade | F060—F064,F076 | HSC00000H | Set bolt | M009 |
| GYM00R/L0-J00 | Modular blade | F026,F034,F086 | HSCX00000H | Set bolt | M009 |
| GYM00R/L0-J00-000 | Modular blade | F066—F068,F078 | HSP05008C | Lock screw | M004 |
| GYM00R/LC-005 | Modular blade | F036 | HSS00000 | Clamp screw | M002 |
| GYPR/L0000000-K00 | GY holder | F028 | HY0 | Bush screw | M004 |

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|--------------|-------------------------------------|---------------------|---------------|-----------------------------------|---------------------------------------|
| HY-A1 | Bush screw | M004 | LLSCN | Shim | M010 |
| HY-V1 | Bush screw | M004 | LLSCP | Shim | M010 |
| I | | | LLSDN | Shim | M010 |
| IMX-LC | Indexable head end mill | I356 | LLSDP42 | Shim | M010 |
| IMX-LS | Indexable head end mill | I357 | LLSRN | Shim | M010 |
| IMX-WR | Wrench (For IMX type end mill) | I356,I357 | LLSSN | Shim | M010 |
| IMX-HV | Indexable head end mill | I338,I339,I349,I351 | LLSSP42 | Shim | M010 |
| IMX-3A | Indexable head end mill | I341,I347 | LLSTE32 | Shim | M011 |
| IMX-4HV | Indexable head end mill | I340,I344,I350 | LLSTN | Shim | M011 |
| IMX-COHV | Indexable head end mill | I342,I345 | LLSTP | Shim | M011 |
| IMX-COT | Indexable head end mill | I353 | LLSWN | Shim | M011 |
| IMX-C4FD-C | Indexable head end mill | I352 | LLSWP | Shim | M011 |
| IMX-C4FV | Indexable head end mill | I346 | LS | Clamp screw | M005 |
| IMX-CH3L | Indexable head end mill | I354 | LS | Clamp screw | M005 |
| IMX-CH6V | Indexable head end mill | I355 | LSOT | Clamp screw | M005 |
| IMX-R4F | Indexable head end mill | I348 | LSOT | Clamp screw | M005 |
| J | | | LS10TS | Clamp screw | M005 |
| JDMT-ZDR | Insert (For AJX/PMC type cutter) | J022,J023,K080,K134 | LS24H | Clamp screw | M005 |
| JDMW-ZDSR-FT | Insert (For AJX/PMC type cutter) | J022,K080,K134 | M | | |
| JFS | JUST FIT SLEEVE set number | L166 | MAE-MB | MAE type drill (External coolant) | L096-L100 |
| JFS | JUST FIT SLEEVE (JFS) | L166 | MAS-LB/MB | MAS type drill (Internal coolant) | L096-L100 |
| JOMT-ZZOR | Insert (For AJX/PMC type cutter) | J022,K080,K134 | MBA-H | Clamp screw | M009 |
| JOMW-ZZSR-FT | Insert (For AJX/PMC type cutter) | J022,K080,K134 | MCLNR-19 | DOUBLE CLAMP holder | C009 |
| JPMT060204-E | Insert (For TAB/CBJP type end mill) | J023,K126 | MCS-X3DB | MCS type drill | L196 |
| JPMX | Insert (For SPX type cutter) | J023,K105 | MES | Spring | C016-C018,C023,F108 G022,H014,H017 |
| JSS | Shim screw | M004 | MGD | Driver | L056 |
| K | | | MGHR/L | MG holder | F108 |
| KGBN | Tool block (For UG holder) | F106 | MGS-LB | MGS type drill | L055 |
| KGC1 | Clamp bridge | M015 | MGS6 | Clamp screw | M005 |
| KGTON | Insert (For UG holder) | F107 | MGTR/L | Insert (For MG holder) | B047,F109,H015,K129 |
| KGTR/L | Insert (For UG holder) | F107 | MHK5NR/L | Clamp bridge | M015 |
| KNUX-R/L-M | Insert (Class U tolerance) | A129 | MHS-LB | MHS type drill | L102-L109 |
| KS | Axial screw | M004 | MHS-R/L | Shim | M011 |
| KS | Set bolt | M004 | MHT1 | Clamp screw | M005 |
| KS-S | Pre-set screw | M004 | MK1K | Anti seize lubricant | M017 |
| KSN | Clamp screw | M008 | MK1KS | Anti seize lubricant | M017 |
| KSS | Clamp screw | M008 | MLCP42 | Shim | M011 |
| KSMGRS | KSMG type end mill | K128 | MLDP42 | Shim | M011 |
| L | | | MLG-L | Insert (For FSL5 type boring bar) | F117,G031 |
| LK1 | Clamp bridge | M015 | MLSP42 | Shim | M011 |
| LLCL | Clamp lever | M013 | MLT-L | Insert (For FSL5 type boring bar) | F117,G031 |
| LLCLS | Clamp lever | M013 | MLTP32 | Shim | M011 |
| LLCS | Clamp screw | M005 | MMS-S/L-DIN | MMS type drill | L058-L069 |
| LLCS-S | Clamp screw | M005 | MMS-S/L-DIN-C | MMS type drill | L058-L069 |
| LLP | Shim pin | M013 | MMS-X-DB | MMS type drill | L058-L069 |
| LLR | Radial screw | M004 | MMT-ER | Insert (For MMTE holder) | G014-G020 |
| | | | MMT-IR | Insert (For MMTI boring bar) | G015-G021 |
| | | | MMTER-C | MMTE holder | G012 |

INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|--------------|--|----------------|------------------|---|---------------------|
| MMTIR | MMTI boring bar | G013 | MS4MC-E | MSTAR end mill | I116 |
| MNS | MNS type drill | L072-L089 | MS4MRB | MSTAR end mill | I088,I089 |
| MNS | MNS type drill | L072-L089 | MS4MRB-E | MSTAR end mill | I125 |
| MNS | MNS type drill DIN6537 | | MS4SC | MSTAR end mill | I059 |
| | (Whistle notch shank type) | L072-L092 | MS4XL | MSTAR end mill | I064-I066 |
| MNS | MNS type drill DIN6537 | | MS6MH-E/MS8MH-E | MSTAR end mill | I120 |
| | (Cylindrical shank type) | L072-L092 | MSBNR | DOUBLE CLAMP holder | C012 |
| MP2MB | MS Plus end mill | I132 | MSCN63 | Shim | M011 |
| MP2SB | MS Plus end mill | I131 | MSE | MSE type drill | L008,L009 |
| MP2SDB | MS Plus end mill | I134 | MSJHD | MSTAR end mill | I055 |
| MP2SSB | MS Plus end mill | I130 | MSL | MSL type drill | L050-L052 |
| MP2XLB | MS Plus end mill | I136-I140 | MSMHD | MSTAR end mill | I052,I053 |
| MP3XB | MS Plus end mill | I144-I146 | MSMHDRB | MSTAR end mill | I091,I092 |
| MP6 | Shim pin | M013 | MSMHZD | MSTAR end mill | I057 |
| MPJHV | MS Plus end mill | I152 | MSP0300SB | MSP type starting drill | L011 |
| MPMHV | MS Plus end mill | I150 | MSSHD | MSTAR end mill | I051 |
| MPMT | Insert (For CBMP/ECMP/TAB type end mill) | J023,K126 | MSSHV/MSMHV | MSTAR end mill | I127,I128 |
| MPMW | Insert (For TSMP type end mill) | J023,K125 | MSSN63 | Shim | M011 |
| MPMX120412 | Insert (For SPX type end mill) | J023,J024,K105 | MSSNR | DOUBLE CLAMP holder | C014 |
| MPS | MPS type drill | L035-L049 | MT1R/L | MT1 type holder | G022 |
| MPS1 | MPS1 type drill DIN6537 | | MTENN | WP holder | C017 |
| | (Whistle notch shank type) | L027-L033 | MTHR/L | MT holder | G022 |
| MPS1 | MPS1 type drill DIN6537 | | MTJNR/L | WP holder | C016 |
| | (Cylindrical shank type) | L027-L033 | MTK | Clamp bridge | M015 |
| MPS1 | MPS1 type drill | L027-L032 | MTQNR/L | WP holder | C018 |
| MS2ES | MSTAR end mill | I068 | MTTR/L | Insert (For MT holder/D type boring head) | G023,H018 |
| MS2JS | MSTAR end mill | I040 | MVS | MVS type drill | L012,L013 |
| MS2LS | MSTAR end mill | I042 | MVX | MVX type drill | L148-L154 |
| MS2MB | MSTAR end mill | I075 | MWE | MWE type drill | L021-L024 |
| MS2MB-E | MSTAR end mill | I123 | MWLNR/L | WP holder | C023 |
| MS2MC-E | MSTAR end mill | I112 | MWS | MWS type drill | L016,L017 |
| MS2MRB | MSTAR end mill | I083,I084 | N | | |
| MS2MS | MSTAR end mill | I037,I038 | NNMU130508ZER-L | Insert (For AHX440S type cutter) | J024,K023 |
| MS2MT | MSTAR end mill | I094-I097 | NNMU1305 | Insert (For AHX440S type cutter) | J024,K023 |
| MS2MTB | MSTAR end mill | I110,I111 | NNMU200 | Insert (For AHX type cutter) | J024,J025,K026,K028 |
| MS2SB | MSTAR end mill | I073,I074 | NNMU200712ZER-MM | Insert (For AHX640S type cutter) | J025,K028 |
| MS2SB-E | MSTAR end mill | I122 | NP-CCGB | Insert (Class G tolerance) | B035 |
| MS2SS | MSTAR end mill | I036 | NP-CCGW | Insert (Class G tolerance) | B036 |
| MS2XL | MSTAR end mill | I044-I046 | NP-CCGW | Insert (Class G tolerance) | B035 |
| MS2XL6 | MSTAR end mill | I048,I049 | NP-CCGW | Insert (Class G tolerance) | B036 |
| MS2XLB | MSTAR end mill | I077-I081 | NP-CCMH | Insert (Class M tolerance) | B051 |
| MS2XLRB | MSTAR end mill | I086 | NP-CCMW | Insert (Class M tolerance) | B051 |
| MS3ES | MSTAR end mill | I069 | NP-CNGA | Insert (Class G tolerance) | B022,B023 |
| MS3MC-E | MSTAR end mill | I114 | NP-CNGA | Insert (Class G tolerance) | B022 |
| MS4EC | MSTAR end mill | I071 | NP-CNGA | Insert (Class G tolerance) | B023 |
| MS4JC | MSTAR end mill | I062 | NP-CNGA | Insert (Class G tolerance) | B022 |
| MS4JC-E | MSTAR end mill | I118 | NP-CNGA | Insert (Class G tolerance) | B022 |
| MS4LT | MSTAR end mill | I099-I104 | NP-CNMM | Insert (Class M tolerance) | B048 |
| MS4LTB | MSTAR end mill | I106-I108 | NP-CPGB | Insert (Class G tolerance) | B037 |
| MS4MC | MSTAR end mill | I060 | NP-CPMH | Insert (Class M tolerance) | B051 |

INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|--------------------|--|----------------|-------------------|---|-----------|
| RPMT0000M0E4 | Insert (For ARP type cutter) | J027,K139 | SECN0000AFON1 | Insert (For SE445•545/LSE445 type cutter) | J028 |
| RPMW0000M0 | Insert (For BRP type cutter) | J028,K089 | SECN0000EFOR/L1 | Insert (For SE415•515/QSE415 type cutter) | J029,J043 |
| RRD0000N000000R | RRD type face mill | K092 | SECN1203AFFR1 | Insert (For SE445 type cutter) | J043 |
| RRD0000P000000R | RRD type face mill | K092 | SEEN0000AFON0 | Insert (For SE445•545 type cutter) | J028 |
| RRD0000R0000M00 | RRD type end mill | K091 | SEEN0000EFOR/L0 | Insert (For SE415•515/QSE415 type cutter) | J029 |
| RRD0000R0000S000 | RRD type end mill | K090 | SEER0000AFEN-JS | Insert (For SE445•545/LSE445 type cutter) | J028,J029 |
| RS0000T | Clamp screw | M006 | SEER1203EFER-JS | Insert (For SE•QSE415 type cutter) | J029 |
| RTG000A | Insert (For TL type holder) | A167,B044,C036 | SEET13T3AGEN-JL | Insert (For ASX445 type cutter) | J030,K019 |
| S | | | SEEW1204AFTN | Insert (For corner angle 45° type cutter) | J029 |
| S0 | Clamp screw | M006 | SEGT13T3AGFN-JP | Insert (For ASX445 type cutter) | J029,K019 |
| S000SCLCR/L00 | S type boring bar (Steel shank) | E031 | SEM1204AZTN | Insert (For corner angle 45° type cutter) | J029 |
| S000SCZCR/L00 | S type boring bar (Steel shank) | E035 | SEMT13T3AGSN-FT | Insert (For ASX445 type cutter) | J030,K019 |
| S000SDQCR/L00 | S type boring bar (Steel shank) | E032 | SEMT13T3AGSN-JH | Insert (For ASX445 type cutter) | J030,K019 |
| S000SDUCR/L00 | S type boring bar (Steel shank) | E030 | SEMT13T3AGSN-JM | Insert (For ASX445 type cutter) | J030,K019 |
| S000SSKCR/L00 | S type boring bar (Steel shank) | E034 | SETK00 | Clamp bridge | M015 |
| S000STFCR/L00 | S type boring bar (Steel shank) | E029 | SETS00 | Clamp screw | M006 |
| S000STFER/L16 | AL type boring bar (Steel shank) | E040 | SFAN0000ZFFR/L2 | Insert (For BF407 type cutter) | J030 |
| S000SVQCR/L00 | S type boring bar (Steel shank) | E033 | SFCN0000ZFFR/L2 | Insert (For BF•QBF407 type cutter) | J030,J043 |
| S000SVUCR/L00 | S type boring bar (Steel shank) | E034 | SG20000000R | SG20 type face mill | K031 |
| SBAHR0000 | Boring holder | D030 | SH000-FSDUCL00 | SH holder | D026 |
| SBAT0000000L | Insert (For SBAHR type holder) | D030 | SL3200-90 | Boring bar sleeve | H022 |
| SBAT0000000L-B | Insert (For SBAHR type holder) | D030 | SLCS000 | Clamp screw | M006 |
| SBH0000R | Square type holder (For MICRO-DEX/MICRO-MINI type boring bar) ... | E025,F114,G029 | SMGHR00000016 | SMG holder | F110,G024 |
| SC00M00S000S/L | Straight arbor | K144 | SMGTR00000000 | Insert (For SMG holder) | F110,G025 |
| SC00M00S000S/LW | Straight arbor (Carbide shank) | K144 | SMTTR00000000 | Insert (For SMT holder) | F110,G025 |
| SC00M00S000-HSK63A | HSK63 arbor | K145 | SNGA0000000 | Insert (Class G tolerance) | A113,B028 |
| SCACR/L00000000-SM | Small tools holder (External front turning) | D008 | SNGG0000000R/L | Insert (Class G tolerance) | A111 |
| SCLCR/L00000000 | SP holder | C024 | SNGN0000000 | Insert (Class G tolerance) | A131,B034 |
| SCLCR/L00000000-SM | Small tools holder (External front turning) | D008 | SNGU0000000AN0R0 | Insert (For WSX445 type cutter) | J030,K012 |
| SCMT0000000 | Insert (Class M tolerance) | A148 | SNMA0000000 | Insert (Class M tolerance) | A113 |
| SCMT0000000-FM | Insert (Class M tolerance) | A147 | SNMF43B2G | Insert (For BN425/DN type cutter) | J031 |
| SCMT0000000-FP | Insert (Class M tolerance) | A147 | SNMG0000000 | Insert (Class M tolerance) | A111 |
| SCMT0000000-FV | Insert (Class M tolerance) | A147 | SNMG0000000-FH | Insert (Class M tolerance) | A108 |
| SCMT0000000-LM | Insert (Class M tolerance) | A147 | SNMG0000000-FS | Insert (Class M tolerance) | A108 |
| SCMT0000000-LP | Insert (Class M tolerance) | A147 | SNMG0000000-FY | Insert (Class M tolerance) | A108 |
| SCMT0000000-MK | Insert (Class M tolerance) | A148 | SNMG0000000-GH | Insert (Class M tolerance) | A112 |
| SCMT0000000-MM | Insert (Class M tolerance) | A147 | SNMG0000000-GK | Insert (Class M tolerance) | A109 |
| SCMT0000000-MP | Insert (Class M tolerance) | A147 | SNMG0000000-GM | Insert (Class M tolerance) | A110 |
| SCMW0000000 | Insert (Class M tolerance) | A148 | SNMG0000000-LK | Insert (Class M tolerance) | A108 |
| SD00 | Set bolt | M006 | SNMG0000000-LM | Insert (Class M tolerance) | A108 |
| SDEN1203AEN | Insert (For corner angle 45° type cutter) | J028 | SNMG0000000-LP | Insert (Class M tolerance) | A108 |
| SDJCR/L00000000 | SP holder | C025 | SNMG0000000-MA | Insert (Class M tolerance) | A110 |
| SDJCR/L00000000-SM | Small tools holder (External front turning) | D009 | SNMG0000000-MH | Insert (Class M tolerance) | A110 |
| SDJER/L000000015 | AL holder | C033 | SNMG0000000-MK | Insert (Class M tolerance) | A109 |
| SDNCN00000000 | SP holder | C025 | SNMG0000000-MM | Insert (Class M tolerance) | A109 |
| SDNCR/L00000000-SM | Small tools holder (External front turning) | D009 | SNMG0000000-MP | Insert (Class M tolerance) | A109 |
| SDNEN000000015 | AL holder | C033 | SNMG0000000-MS | Insert (Class M tolerance) | A110 |
| | | | SNMG0000000R/L-1G | Insert (Class M tolerance) | A109 |
| | | | SNMG0000000-RK | Insert (Class M tolerance) | A111 |
| | | | SNMG0000000-RM | Insert (Class M tolerance) | A111 |

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|---|--|---------------------|--|---|---------------------|
| SNMG RP | Insert (Class M tolerance) | A111 | SRK1R | Clamp bridge | M015 |
| SNMG RS | Insert (Class M tolerance) | A111 | SRM C-M | Insert (For SRM2 type end mill)..... | J035,K122 |
| SNMG SA | Insert (Class M tolerance) | A109 | SRM E-M | Insert (For SRM2 type end mill)..... | J035,K122 |
| SNMG SH | Insert (Class M tolerance) | A108 | SRM2 AM S/L | SRM2 type end mill | K117 |
| SNMG SY | Insert (Class M tolerance) | A109 | SRM2 IONL M/S | SRM2 type end mill | K121 |
| SNMM HL | Insert (Class M tolerance) | A112 | SRM2 M L | SRM2 type end mill | K117 |
| SNMM HM | Insert (Class M tolerance) | A112 | SRM2 MNLM S | SRM2 type end mill | K121 |
| SNMM HR | Insert (Class M tolerance) | A113 | SRM2 S | SRM2 type end mill | K116,K117 |
| SNMM HV | Insert (Class M tolerance) | A113 | SRM2 SNLM S | SRM2 type end mill | K117 |
| SNMM HX | Insert (Class M tolerance) | A112 | SRM2 WNLL M/S/X | SRM2 type end mill | K117 |
| SNMM HXD | Insert (Class M tolerance) | A113 | SRS5 | Clamp screw | M006 |
| SNMM HZ | Insert (Class M tolerance) | A112 | SSSCR L | SP holder | C028 |
| SNMN | Insert (Class M tolerance) | A131,J031 | STASX N | Shim | M012 |
| SNMU ANER | Insert (For WSX445 type cutter)..... | J030,K012 | STAW N S | STAW type drill | L113—L122 |
| SOET12T308PEER JL | Insert (For ASX400 type cutter)..... | J031,K038 | STAW S S | STAW type drill | L113—L122 |
| SOGT12T308PEFR JP | Insert (For ASX400 type cutter)..... | J031,K038 | STAWK TG | Insert (For STAW type drill) ... | L113—L122,L125,L126 |
| SOMT12T308PEER L | Insert (For ASX400 type cutter)..... | J031,K038 | TAWN T | Insert (For STAW type drill) ... | L118—L122,L124 |
| SOMX | Insert (For MVX type drill)..... | L155 | STAWN TH | Insert (For STAW type drill) ... | L113—L118,L123,L124 |
| SONX1206PER L | Insert (For VOX400 type cutter) | J032,K033 | STBS500N | Shim | M012 |
| SPEN EDR L | Insert (For corner angle 15°type cutter) | J032 | STFER L 16 | AL holder | C034 |
| SPEN EE R/L1 | Insert (For FBP415/QBP415 type cutter) ... | J032,J043 | STGCR L | SP holder | C029 |
| SPEN CA | Insert (For FP490•590•690 type cutter)..... | J032 | STGER L 16 | AL holder | C034 |
| SPER1203EEER JS | Insert (For FBP415/QBP415 type cutter) ... | J032 | STPMR N | Shim (For PMR type end mill) | K132 |
| SPGN | Insert (Class G tolerance) ... | A168,B044,B057,J032 | STS1 | Shim screw | M006 |
| SPGX | Insert (Class G tolerance)..... | A149,B053 | SUFT R | Insert (For SUF type end mill) | J035,K114 |
| SPKN1203EDR | Insert (For corner angle 15°type cutter) | J032 | SVJBR L SM | Small tools holder (External front turning) ... | D010 |
| SPMB1204APT | Insert (For BSP type end mill) | J033 | SVJCR L | SP holder | C030 |
| SPMN | Insert (Class M tolerance) | A168,J032 | SVJDR L 16 | AL holder | C035 |
| SPMN T | Insert (Class M tolerance) | A168,J032 | SVLPR L SM | Small tools holder (External front turning) ... | D010 |
| SPMR | Insert (Class M tolerance) | A168 | SVPCR L 16 | SP holder | C031 |
| SPMR 80 | Insert (Class M tolerance) | A168 | SVPPR L SM | Small tools holder (External front turning) ... | D011 |
| SPMT | Insert (Class M tolerance) | A149 | SVVBR L SM | Small tools holder (External front turning) ... | D011 |
| SPMT120408 A | Insert (For TBE1 type end mill)..... | J033 | SVVCN L 16 | SP holder | C030 |
| SPMW | Insert (Class M tolerance) | A149,J033,K124 | SXZCR L 15 | Profile holder | C032 |
| SPMX120408 | Insert (For SPX type end mill) | J033,K105 | T | | |
| SPNN1203EDR | Insert (For corner angle 15°type cutter) | J033 | TAFL M/S F | TAF type drill | L158—L162 |
| SPNN1203EEER L1 | Insert (For FBP•QBP415 type cutter) | J032 | TAFL M/S F E | TAF type drill | L163 |
| SPS | Locator screw | M006 | TAW N S | TAW type drill (General use) | L129—L141 |
| SPSG20R | Locator (For SG20 type cutter)..... | K031 | TAWKH TG | Insert (For TAW type drill) ... | L129—L141,L144,L145 |
| SPSVN32 | Shim | M012 | TAWNH T | Insert (For TAW type drill) | L129—L143 |
| SPX4 A24A058RA | SPX type end mill | K104 | TBGN | Insert (Class G tolerance)..... | B045 |
| SPX4R0 SK50N | SPX type end mill | K103 | TCGT AZ | Insert (Class G tolerance)..... | A150 |
| SRBT | Insert (For SRB type)..... | J034,K110 | TCGT R/L F | Insert (Class G tolerance)..... | A150 |
| SRDCN | SP holder | C027 | TCGW | Insert (Class G tolerance)..... | B053 |
| SRFH AM | SRF type end mill | K109,K113 | TCGW FS | Insert (Class G tolerance)..... | B040 |
| SRFH S | SRF type end mill | K108,K109,K112,K113 | TCMT | Insert (Class M tolerance) | A151 |
| SRFT | Insert (For SRF type end mill) | J034,K110 | TCMT FM | Insert (Class M tolerance) | A150 |
| SRG C | Insert (For SRM2 type end mill)..... | J034,K122 | TCMT FP | Insert (Class M tolerance) | A150 |
| SRG E | Insert (For SRM2 type end mill)..... | J034,K122 | TCMT FV | Insert (Class M tolerance) | A150 |
| SRGCR L | SP holder | C027 | | | |

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|--------------|----------------------------|----------------|--------------|----------------------------|---------------------|
| UGS | Wrench (For UG holder) | F106,F107 | VDGX | Insert (Class G tolerance) | A161 |
| V | | | VDGX | Insert (Class G tolerance) | B055 |
| VA2MS | VIOLET end mill | I319 | VF2MV | IMPACT MIRACLE end mill | I157 |
| VA2SS | VIOLET end mill | I318 | VF2SB | IMPACT MIRACLE end mill | I178,I179 |
| VA4MC | VIOLET end mill | I321 | VF2SDB | IMPACT MIRACLE end mill | I180 |
| VAJR | VIOLET end mill | I329 | VF2SDBL | IMPACT MIRACLE end mill | I181 |
| VALR | VIOLET end mill | I331 | VF2SSB | IMPACT MIRACLE end mill | I177 |
| VAMFPR | VIOLET end mill | I325 | VF2WB | IMPACT MIRACLE end mill | I176 |
| VAMH | VIOLET end mill | I333 | VF2XL | IMPACT MIRACLE end mill | I154,I155 |
| VAMR | VIOLET end mill | I327 | VF2XLB | IMPACT MIRACLE end mill | I184-I188 |
| VAPDM | VIOLET drill | L174-L176 | VF2XLBS | IMPACT MIRACLE end mill | I183 |
| VAPDMSUS | VIOLET drill | L184-L189 | VF3XB | IMPACT MIRACLE end mill | I190-I192 |
| VAPDS | VIOLET drill | L169-L172 | VF4MB | IMPACT MIRACLE end mill | I195 |
| VAPDSCB | VIOLET drill | L193,L194 | VF4MV | IMPACT MIRACLE end mill | I159 |
| VAPDSSUS | VIOLET drill | L178-L183 | VF4SVB | IMPACT MIRACLE end mill | I197 |
| VASFPR | VIOLET end mill | I323 | VF6MHV | IMPACT MIRACLE end mill | I165 |
| VBET | Insert (Class E tolerance) | A158 | VF6MHVCH | IMPACT MIRACLE end mill | I166 |
| VBET | Insert (Class E tolerance) | A157 | VF6MHVRB | IMPACT MIRACLE end mill | I213 |
| VBET | Insert (Class E tolerance) | A158 | VF6MHVRBCH | IMPACT MIRACLE end mill | I215 |
| VBGT | Insert (Class G tolerance) | A156 | VF6SVRCH | IMPACT MIRACLE end mill | I174 |
| VBMT | Insert (Class M tolerance) | A157 | VF8MHVCH | IMPACT MIRACLE end mill | I167 |
| VBMT | Insert (Class M tolerance) | A156 | VF8MHVRBCH | IMPACT MIRACLE end mill | I216 |
| VBMT | Insert (Class M tolerance) | A156 | VFFDRB | IMPACT MIRACLE end mill | I209 |
| VBMT | Insert (Class M tolerance) | A156 | VFHVRB | IMPACT MIRACLE end mill | I199,I200,I205,I206 |
| VBMT | Insert (Class M tolerance) | A156 | VFJHV | IMPACT MIRACLE end mill | I163 |
| VBMT | Insert (Class M tolerance) | A156 | VFMD | IMPACT MIRACLE end mill | I169 |
| VBMT | Insert (Class M tolerance) | A156 | VFMDRB | IMPACT MIRACLE end mill | I218 |
| VBMT | Insert (Class M tolerance) | A157 | VFMFPR | IMPACT MIRACLE end mill | I175 |
| VBMT | Insert (Class M tolerance) | A157 | VFMHV | IMPACT MIRACLE end mill | I160 |
| VBMT | Insert (Class M tolerance) | A157 | VFMHVCH | IMPACT MIRACLE end mill | I162 |
| VBMT | Insert (Class M tolerance) | A157 | VFMHVRB | IMPACT MIRACLE end mill | I210 |
| VBMT | Insert (Class M tolerance) | A157 | VFMHVRBCH | IMPACT MIRACLE end mill | I212 |
| VBMW | Insert (Class M tolerance) | A157 | VFSD | IMPACT MIRACLE end mill | I168 |
| VC2PSB | MIRACLE end mill | I250 | VFSDRB | IMPACT MIRACLE end mill | I217 |
| VC2PSBP | MIRACLE end mill | I251 | VFSFPR | IMPACT MIRACLE end mill | I171 |
| VCGT | Insert (Class G tolerance) | A159 | VFSFPRCH | IMPACT MIRACLE end mill | I173 |
| VCGT | Insert (Class G tolerance) | A159 | VFX5 | VFX5 type end mill | K094 |
| VCMT | Insert (Class M tolerance) | A160 | VFX6 | VFX6 type end mill | K097 |
| VCMT | Insert (Class M tolerance) | A159 | VNGA | Insert (Class G tolerance) | A123,B050 |
| VCMT | Insert (Class M tolerance) | A159 | VNGG | Insert (Class G tolerance) | A120 |
| VCMT | Insert (Class M tolerance) | A159 | VNGG | Insert (Class G tolerance) | A123 |
| VCMT | Insert (Class M tolerance) | A159 | VNGG | Insert (Class G tolerance) | A120 |
| VCMT | Insert (Class M tolerance) | A159 | VNGM | Insert (Class G tolerance) | A121 |
| VCMT | Insert (Class M tolerance) | A160 | VNMA | Insert (Class M tolerance) | A123 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A122 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A120 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A120 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A122 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A122 |
| VCMT | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A122 |
| VCMW | Insert (Class M tolerance) | A160 | VNMG | Insert (Class M tolerance) | A121 |
| VCPSRB | MIRACLE end mill | I253-I255,I257 | | | |

INDEX FOR TOOL NUMBER

| Order Number | PRODUCT NAME | Page | Order Number | PRODUCT NAME | Page |
|------------------|---|------------------|-------------------|--|------------|
| VNMG○○○○○○-LM | Insert (Class M tolerance) | A120 | WNMG○○○○○○-LM | Insert (Class M tolerance) | A124 |
| VNMG○○○○○○-LP | Insert (Class M tolerance) | A120 | WNMG○○○○○○-LP | Insert (Class M tolerance) | A124 |
| VNMG○○○○○○-LS | Insert (Class M tolerance) | A121 | WNMG○○○○○○-LS | Insert (Class M tolerance) | A125 |
| VNMG○○○○○○-MA | Insert (Class M tolerance) | A122 | WNMG○○○○○○-MA | Insert (Class M tolerance) | A126 |
| VNMG○○○○○○-MH | Insert (Class M tolerance) | A122 | WNMG○○○○○○-MH | Insert (Class M tolerance) | A127 |
| VNMG○○○○○○-MJ | Insert (Class M tolerance) | A121 | WNMG○○○○○○-MJ | Insert (Class M tolerance) | A125 |
| VNMG○○○○○○-MK | Insert (Class M tolerance) | A122 | WNMG○○○○○○-MK | Insert (Class M tolerance) | A126 |
| VNMG○○○○○○-MM | Insert (Class M tolerance) | A121 | WNMG○○○○○○-MM | Insert (Class M tolerance) | A126 |
| VNMG○○○○○○-MP | Insert (Class M tolerance) | A121 | WNMG○○○○○○-MP | Insert (Class M tolerance) | A125 |
| VNMG○○○○○○-MS | Insert (Class M tolerance) | A122 | WNMG○○○○○○-MS | Insert (Class M tolerance) | A126 |
| VNMG○○○○○○-SA | Insert (Class M tolerance) | A121 | WNMG○○○○○○-MW | Insert (Class M tolerance) | A127 |
| VNMG○○○○○○-SH | Insert (Class M tolerance) | A121 | WNMG○○○○○○-RK | Insert (Class M tolerance) | A127 |
| VOX400-○○○○○○R | VOX400 type face mill | K032 | WNMG○○○○○○-RM | Insert (Class M tolerance) | A127 |
| VPET○○○○○○-SRF | Insert (Class E tolerance) | A162 | WNMG○○○○○○-RP | Insert (Class M tolerance) | A127 |
| VPGT○○○○○○-SMG | Insert (Class G tolerance) | A162 | WNMG○○○○○○-RS | Insert (Class M tolerance) | A127 |
| VQ4SVB | VQ end mill | I241 | WNMG○○○○○○-SA | Insert (Class M tolerance) | A125 |
| VQJHV | VQ end mill | I233 | WNMG○○○○○○-SH | Insert (Class M tolerance) | A125 |
| VQMHV | VQ end mill | I229 | WNMG○○○○○○-SW | Insert (Class M tolerance) | A125 |
| VQMHRVB | VQ end mill | I243, I244 | WNMG○○○○○○-SY | Insert (Class M tolerance) | A125 |
| VQMHRBF | VQ end mill | I248 | WOW12T308PEOR8C | Wiper insert (For ASX400 type cutter) | J042, K038 |
| VQMHZV | VQ end mill | I220, I221 | WOEX1206PER5C | Insert (For VOX400 type cutter) | J042, K033 |
| VQMHZVOH | VQ end mill | I226 | WPC42EEO10C | Wiper insert (For FBP415/QBP415 type cutter) | J042 |
| VQSVR | VQ end mill | I238 | WPGT○○○○○○ | Insert (Class G tolerance) | B056 |
| VQXL | VQ end mill | I235 | WPGT○○○○○○R/L-FS | Insert (Class G tolerance) | A165 |
| VSD | VIOLET drill, Straight shank | L191, L192 | WPMT○○○○○○-MV | Insert (Class M tolerance) | A165 |
| W | | | WPSTN○○ | Shim | M012 |
| WBGTO○○○○○○R/L-F | Insert (Class G tolerance) | A163 | WPSWC43 | Shim | M012 |
| WBMT○○○○○○R/L-MV | Insert (Class M tolerance) | A163 | WPSWN43 | Shim | M012 |
| WCGTO○○○○○○R/L | Insert (Class G tolerance) | A164 | WPT4405 | Plate (For TAW drill) | L129—L141 |
| WCMT○○○○○○ | Insert (Class M tolerance) | A164 | WS○○○○○○TPS | Clamp screw | M008 |
| WCMW○○○○○○ | Insert (Class M tolerance) | B056 | WS○○○○○○T | Clamp screw | M008 |
| WCS○○○○○○H | Shim screw | M008 | WS1 | Wedge screw | M008 |
| WEC○○AFOR/L5C | Wiper insert (For SE445•545/LSE445 type cutter) | J041 | WSX445-○○○○○○OR | WSX445 type face mill | K010 |
| WEC○○EFOR/L5C | Wiper insert (For SE415•515 type cutter) | J041 | WSX445R○○○○SA32M | WSX445 type end mill | K011 |
| WEEW13T3AGOR3C | Wiper insert (For ASX445 type cutter) | J044, K019 | X | | |
| WEEW13T3AGOR8C | Wiper insert (For ASX445 type cutter) | J041, K019 | XCMT○○○○○○-SVX | Insert (Class M tolerance) | A166 |
| WFC42ZFER/L2 | Wiper insert (For BF407/QBF407 type cutter) | J044 | XDGT1550PDER-G○○ | Insert (For BXD4000 type cutter) | J038, K066 |
| WNEU200ZEN7C-○○ | Wiper insert (For AHX type cutter) | J041, K026, K028 | XDGT1550PDFR-G○○ | Insert (For BXD4000•7000 type cutter) | J038, K066 |
| WNGU1406ANEN8C-M | Wiper Insert (For WSX445 type cutter) | J042, K012 | XDGT1550PDFR-GL○○ | Insert (For BXD4000•7000 type cutter) | J038, K066 |
| WNMA○○○○○○ | Insert (Class M tolerance) | A128 | XDGX○○○○○○PDER-GM | Insert (For AXD4000 type cutter) | J039, K056 |
| WNMG○○○○○○ | Insert (Class M tolerance) | A127 | XDGX○○○○○○PDFR-GL | Insert (For AXD4000•7000 type cutter) | J038 |
| WNMG○○○○○○-FH | Insert (Class M tolerance) | A124 | | J039, K056, K061 | |
| WNMG○○○○○○-FS | Insert (Class M tolerance) | A124 | XDGX○○○○○○PDFR-GM | Insert (For AXD4000 type cutter) | J039, K056 |
| WNMG○○○○○○-FY | Insert (Class M tolerance) | A124 | XNMU○○○○○○R-OS | Insert (For VFX5•VFX6 type cutter) | J039, J040 |
| WNMG○○○○○○-GH | Insert (Class M tolerance) | A127 | | K095, K098 | |
| WNMG○○○○○○-GJ | Insert (Class M tolerance) | A128 | Z | | |
| WNMG○○○○○○-GK | Insert (Class M tolerance) | A126 | ZCMX○○○○○○ER-○ | Insert (For DCCC type end mill) | J040, K101 |
| WNMG○○○○○○-GM | Insert (Class M tolerance) | A126 | ZRM0603R-M○ | Insert (For BAP300 type cutter) | J040 |
| WNMG○○○○○○-LK | Insert (Class M tolerance) | A124 | | | |

Memo

A series of horizontal dotted lines for writing, spanning the width of the page.

Memo

A series of horizontal dashed lines for writing, spanning the width of the page.

Memo

A series of horizontal dotted lines for writing, spanning the width of the page.

Memo

A series of horizontal dashed lines for writing, spanning the width of the page.



www.mitsubishicarbide.com | www.mmc-hardmetal.com

MMC HARTMETALL GMBH

Comeniusstr. 2 . 40670 Meerbusch . Germany
Phone +49 2159 91890 . Fax +49 2159 918966
Email admin@mmchg.de

MMC HARDMETAL U.K. LTD.

Mitsubishi House . Galena Close . Tamworth . Staffs. B77 4AS . U.K.
Phone +44 1827 312312 . Fax +44 1827 312314
Email sales@mitsubishicarbide.co.uk

MMC METAL FRANCE S.A.R.L.

6, Rue Jacques Monod . 91400 Orsay . France
Phone +33 1 69 35 53 53 . Fax +33 1 69 35 53 50
Email mmfsales@mmc-metal-france.fr

mitsubishi materials españa, s.a.

Calle Emperador 2 . 46136 Museros/Valencia . Spain
Phone +34 96 1441711 . Fax +34 96 1443786
Email mme@mmevalencia.com

MMC HARTMETALL GMBH ALMANYA – İZMİR MERKEZ ŞUBESİ

Adalet Mahallesi Anadolu Caddesi No: 41-1 . 15001 35580 Bayraklı/İzmir . Turkey
Phone +90 232 5015000 . Fax +90 232 5015007
Email info@mmchg.com.tr

MMC HARDMETAL POLAND SP. Z O. O.

Al. Armii Krajowej 61 . 50-541 Wrocław . Poland
Phone +48 71335 1620 . Fax +48 71335 1621
Email sales@mitsubishicarbide.com.pl

MMC HARDMETAL RUSSIA 000 LTD.

Electrozavodskaya Str. 24 . build. 3 107023 Moscow . Russia
Phone +7 495 7255885 . Fax +7 495 9813979
Email info@mmc-carbide.ru

MMC ITALIA S. R. L.

Via Montefeltro 6/A . 20156 Milano . Italy
Phone +39 0293 77031 . Fax +39 0293 589093
Email info@mmc-italia.it

DISTRIBUTED BY:

□ □

└ ┘